



**Corrosion  
Engineering™**

AN ERGONARMOR COMPANY

**TECHNICAL INFORMATION**

**CES-295**

**03/00 SUPERSEDES 04/99 PAGE 1 OF 5**

## ***CORROSION ENGINEERING SPECIFICATION FOR INSTALLATION OF***

### ***FURALAC® MEMBRANE***

#### **1. SCOPE**

- 1.1 This specification governs the installation of FURALAC Membrane Lining System as manufactured by Corrosion Engineering for the protection of concrete and steel structures.
- 1.2 This specification shall also be used with the following product data sheets:  
CE-139 - PENNTROWEL® Epoxy Primer  
CE-227 - PENNGUARD® Block Primer  
CE-196 - TUFCEM® II Membrane  
CE-295 - FURALAC Membrane
- 1.3 The thickness of the FURALAC Membrane as set forth in this specification is 1/8" - 3/16" (125 - 187 mils). Other thicknesses and different reinforcement mats or woven roving may be specified depending upon the service conditions.
- 1.4 For hydrofluoric acid or strong caustic service conditions, inert synthetic veils are available for use with this membrane system. Contact Corrosion Engineering for details.

#### **2. SYSTEM DESCRIPTION AND MATERIALS**

##### **2.1 System Description**

- 2.1.1 The FURALAC Membrane System is a multi layer glass mat reinforced lining system consisting of 3 main components - the primer, the stress relieving layer, and the laminate membrane.

**CES-295 - FURALAC MEMBRANE INSTALLATION SPECIFICATION**  
**03/00 SUPERSEDES 04/99 PAGE 2 OF 5**

2.1.2 The system is installed in the following steps:

- A) - Primer - varies with substrate
- B) - Flexible base layer
- C) - 1.5 oz glass mat (cloth layer #1)
- D) - FURALAC Membrane saturant
- E) - 1.5 oz glass mat (cloth layer #2)
- F) - FURALAC Membrane saturant
- G) - 1.0 oz glass mat (cloth layer #3)
- H) - FURALAC Membrane saturant
- I) - FURALAC Membrane final seal coat
- J) - Sand broadcast layer

## 2.2 Concrete Substrates

2.2.1 Primer: PENNTROWEL® Epoxy Primer, Data Sheet CE-139.  
Flexible base layer: TUFCEM® II Membrane, Data Sheet CE-196.  
Furan laminate membrane: FURALAC Membrane, Data Sheet CE-295.

2.2.2 All of the materials in 2.2.1 are manufactured by Corrosion Engineering.

## 2.3 Steel Substrates

2.3.1 Primer: PENNGUARD® Block Primer, Data sheet CE-227  
Flexible base layer: TUFCEM II Membrane, Data sheet CE-196.  
Furan laminate membrane: FURALAC Membrane, Data sheet CE-295.

2.3.2 All of the materials in 2.3.1 are manufactured by Corrosion Engineering.

# 3. **SURFACE PREPARATION**

## 3.1 Concrete Substrate

3.1.1 When the application of the FURALAC Membrane is to be onto a concrete substrate, the concrete shall be prepared in accordance with the "Surface Preparation" section of the latest edition of Corrosion Engineering Specification for Installation PENNCHEM® 97 and TUFCEM II Membranes On Concrete (CES-334).

## 3.2 Steel Substrate

**FURALAC<sup>®</sup> MEMBRANE SPECIFICATION FOR INSTALLATION**  
**CES-295**  
**03/00 SUPERSEDES 04/99 PAGE 3 OF 5**

- 3.2.1 When the application of the FURALAC Membrane is to be onto a steel substrate, the steel shall be prepared in accordance with the "Surface Preparation" section of the latest edition of Corrosion Engineering Specification for Installation TUFCEM II and PENNCHEM 97 Installation On Steel (CES-326).

#### **4. PRIMING**

##### 4.1 Concrete Substrate

- 4.1.1 The prepared concrete shall be primed in accordance with section "4. PRIMING" of the latest edition of Corrosion Engineering Specification for Installation PENNCHEM 97 and TUFCEM II Membranes (CES-334).

##### 4.2 Steel Substrate

- 4.2.1 The prepared steel shall be primed in accordance with section 4.1 of the latest edition of Corrosion Engineering Specification for Installation TUFCEM II and PENNCHEM 97 Installation On Steel (CES-326).

#### **5. APPLICATION**

- 5.1 The temperature of the prepared substrate and the ambient air temperature immediate to the surface to be lined shall be between 50°F - 90°F, and the surface temperature shall be at least 5°F above the moisture condensation dewpoint.
- 5.2 The application of the FURALAC Membrane is not to be performed in direct hot sunlight.
- 5.3 The TUFCEM<sup>®</sup> II Membrane shall be stored and mixed in accordance with Section 5. of the latest edition of Corrosion Engineering Specification For Installation PENNCHEM<sup>®</sup> 97 and TUFCEM<sup>®</sup> II Membranes (CES-334).
- 5.4 After mixing the TUFCEM II Membrane, it shall be troweled onto the hardened primed substrate to a thickness of 1/16" (60 mils) unless otherwise specified.

**FURALAC<sup>®</sup> MEMBRANE SPECIFICATION FOR INSTALLATION**  
**CES-295**

**03/00 SUPERSEDES 04/99 PAGE 4 OF 5**

- 5.5 One layer of 1.5 oz. chopped strand glass mat shall be carefully rolled into the applied layer of the TUFCEM II Membrane while it is still wet. Be sure to eliminate any wrinkles. Use of a serrated roller typically used in the FRP laminating industry is strongly suggested. Overlap edge seams of the mat 2". Use this wet base layer to serve as an adhesive for holding the chopped strand glass mat in place. Do not saturate the glass mat with the TUFCEM<sup>®</sup> II Membrane. Allow this installation to cure to a firm rubbery state - typically 12 - 16 hours.
- 5.6 Mix FURALAC Membrane Resin together with FURALAC Membrane Hardener as per the labels on the containers. The mix ratio of FURALAC Membrane Resin to FURALAC Membrane Hardener is 100 : 3.5 (by weight) and 100 : 3.2 (by volume). (One U.S. gallon Resin : 0.5 cup Hardener.) Mix only sufficient Resin and Hardener to saturate the layer of reinforcing glass mat that was placed into the TUFCEM II Membrane. **IT IS TO BE NOTED THAT THE POT LIFE OF THE LAMINATING FURALAC MEMBRANE RESIN / HARDENER MIXTURE IS VERY SHORT. GOVERN THE SIZE OF THE WORK AREA ACCORDINGLY.**
- 5.7 The mixed FURALAC Membrane Resin and FURALAC Membrane Hardener shall be removed from the mixing container and immediately rolled onto the glass mat layer embedded into the TUFCEM II Membrane. **IF THE MIXED RESIN / HARDENER IS LEFT IN THE MIXING CONTAINER IN A MASS, A VIOLENT EXOTHERMIC REACTION MAY OCCUR, CAUSING SEVERE BURNS.**
- 5.8 Once the layer of glass mat has been fully saturated with the laminating FURALAC<sup>®</sup> Membrane Resin/Hardener mixture, a second layer of 1.5 oz. chopped strand glass mat shall be rolled onto the wet surface using a serrated roller, and again overlapping all seams 2".
- 5.9 This second layer of mat is to also be saturated with the laminating FURALAC Membrane Resin/Hardener saturant as per sections 5.6 and 5.7.
- 5.10 Roll into this second saturated mat layer, one layer of 1 oz chopped strand glass mat reinforcing and saturate this thin surface veil with the laminating FURALAC Membrane Resin / Hardener mixture. Overlap all edge seams 2". Let the application cure hard - typically 3 - 4 hours.
- 5.11 Apply a final thin coat of the laminating FURALAC Membrane Resin/Hardener mixture with a roller. Into this wet coat shall be lightly broadcast #3Q sand at a coverage rate on the order of 350 sq. ft. / gallon of sand. This is to enhance the bonding of the subsequent chemical-

**FURALAC® MEMBRANE SPECIFICATION FOR INSTALLATION**  
**CES-295**  
**03/00 SUPERSEDES 04/99 PAGE 5 OF 5**

resistant masonry lining that is to be installed.

- 5.12 Allow the membrane system to cure for 24 hours at a minimum of 70°F.
- 5.13 In order to maximize the intercoat adhesion between the various layers, it is important that steps 5.6 through 5.11 are performed without interruption especially when ambient installation temperatures are above 80°F.
- 5.14 The thickness of the cured FURALAC Membrane will be between 1/8" - 3/16" (125 - 187 mils).

**6. SAFETY PRECAUTIONS AND DISCLAIMER**

- 6. Corrosion Engineering FURALAC Membrane components, PENNTROWEL® Epoxy Primer, PENNGUARD® Block Primer, TUFCEM® II Membrane and mixes of them present a number of hazards. Read before using and follow the hazard information, precautions, and first aid directions on the individual product labels and Material Safety Data Sheets.
- 6.2 The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, Corrosion Engineering expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before installation. Nothing contained herein should be taken as an inducement to infringe any patent and the user is advised to take appropriate steps to be assured that any proposed use of the product will not result in patent infringement.
- 6.3 Please contact Corrosion Engineering for specific recommendations at +1-610-833-4000 or fax +1-610-833-3040.

**[www.furalac.com](http://www.furalac.com)**